



100MM SINGLEDISC MB100 BALUSTRADE SYSTEM

Installation / Fitting Instructions

SIDE FIX (MB100) – Heavy Weight Anchor





Product	Installation/Fitting Instructions
<p>Structure Fastening Installation Typical Layout of SingleDisc MB100 – Heavy Weight Anchors.</p> 	<ul style="list-style-type: none"> • Verify the mounting structure can withstand the loads required for installation prior to fixing balustrade. • Using laser level or string line, cast level lines horizontally and vertically to find the centre points of the fastenings required for the building structure as detailed in the PS1. <ul style="list-style-type: none"> – Minimum edge distance from top of structure to centre line of fixing is 90mm for $H < 1150\text{mm}$ or 100mm for $1150\text{mm} < H < 1250\text{mm}$. – Fixing layout centres are calculated as: min 100mm, max 200mm in from glass edges; equal spacing's between corner fixings to match PS1 design tables.
<p>Backing Disc Installation Structural fastening into backing Disc Tolerance.</p> 	<ul style="list-style-type: none"> • Install fastenings as per the given PS1 for structure type. • Fix SingleDisc MB100 backing disc to the fastening. <ul style="list-style-type: none"> – Ensure the backing discs are all on a level plane. If the building structure is not level: <ul style="list-style-type: none"> – Add fibre gaskets (3 gaskets max.) or additional custom disc to a maximum of 75mm.

IMPORTANT NOTE: The guide above is simplified, and should in no way be referenced in isolation. For full comprehensive substrate fixing details please refer through to the PS1.

100MM SINGLEDISC MB100 BALUSTRADE SYSTEM

Installation / Fitting Instructions

Product	Installation/Fitting Instructions
<p>Glass Installation</p> 	<ul style="list-style-type: none"> • NOTE: when ordering glass ensure the hole diameters are 26mm. • Check that the hole locations in the glass panels align with the backing disc locations. <ul style="list-style-type: none"> – SingleDisc MB100 anchor M12 bushes can be changed to M12 slotted bushes to allow for 2.0mm adjustment horizontally if required. • Install glass panels. <ul style="list-style-type: none"> – For SingleDisc MB100 Heavy Weight Anchor – use black fibre gasket to backing disc surface, suitable bush for tolerance (thickness to suit the glass t), black fibre gasket to outer disc and M12 fastening (length to suit the glass t). • Fix the SingleDisc MB100 front disc through the glass panel to the backing disc, tightening to 40Nm. <ul style="list-style-type: none"> – M12 fastening must not clash with building structure fastening inside the backing disc.
<p>Final Adjustment</p> 	<ol style="list-style-type: none"> 1. Check Glass panel gaps, levels and alignments of frit or similar pattern details. Align with setting blocks and/ or spacers to suit. 2. Check SingleDisc MB100 anchors have been torqued to 40Nm.
<p>Cleaning</p>	<p>Once everything is correctly in place and the job is complete, the glass and disc need to be cleaned. Use a non-abrasive glass cleaner on the glass and warm soapy water on the SingleDisc MB100 disc. We also recommend a soft sponge or cloth, again to avoid any risk of scratching. For full care and maintenance guidelines please refer to our comprehensive guide pages 778-779.</p>

IMPORTANT NOTE: The guide above is simplified, and should in no way be referenced in isolation. For full comprehensive substrate fixing details please refer through to the PS1.